


OVEN CONTROL GUIDE

Setting the Clock and Minute Timer



To Set the Clock

When the appliance is first plugged in, or when the power supply to the appliance has been interrupted, "12:00" will flash in the display window.


1. Press pad **C** (CLOCK).
2. Press and hold pad **A** (HOUR) until the correct hour appears in the display. (The numbers will only count forward.)
3. Press and hold pad **B** (MINUTE) until the correct minutes appear in the display.

To Set the Minute Timer


1. Press pad **D** (TIMER), "0:59" (59 MINUTES) will appear. The timer can be set for any amount of time from 1 minute to 1 hour and 59 minutes.
2. To set a time more than 59 minutes, press and release pad **A** (HOUR). The timer will jump in at the maximum 1 hour and 59 minutes. Adjust the time by pressing and holding pad **B** (MINUTE) until the correct time appears in the display. The minute timer will automatically start when the pad is released.
3. When the set time has passed, the control will display "0:00" and beep continuously. Press pad **C** (CLOCK) to cancel the timer and return to the clock mode.

Versión en español. Si desea obtener una copia en español de este Manual, sírvase escribir a la dirección que se incluye a continuación. Solicite la P/N 318201137.
Spanish Owner's Guides
Frigidaire Company
P.O. Box 9061

Setting Oven Controls



The broiler pan and its grid allow dripping grease to drain and be kept away from the high heat of the broiler. **DO NOT** use the pan without its grid. **DO NOT** cover the grid with foil. The exposed grease could ignite.




To Bake

1. Arrange oven racks while the oven is still cool.
2. Push in and turn the Temperature Control knob to the desired oven temperature. When the oven is first turned on, the oven indicator light (some models) under the Temperature Control knob will glow.
3. Preheat the oven for 10 to 12 minutes before baking. Preheating is not necessary when roasting, cooking casseroles or broiling most foods. When the desired temperature is reached, the oven indicator light will go out.
4. When cooking is finished, turn the Temperature Control knob to OFF.

To Broil


1. Pull out broiler drawer.
2. Arrange oven rack while broiler is still cool. For rare meats, position the broiler pan closer to the burner (upper position). For well-done foods such as chicken, lobster tails or thick cuts of meat, position the pan further from the burner (lower position).
3. Push in and turn the Temperature Control knob to BROIL. You may adjust the Temperature Control knob down to avoid excess browning or drying of foods that should be cooked to the well-done stage.
4. Place the grid on the broiler pan, and then place the meat on the grid. **DO NOT** use the broiler pan without the grid or cover the grid with aluminum foil. The exposed fat could ignite.
5. Push in the drawer and **close the door**.
6. Broil on one side until food is browned; turn and cook on the second side. Season and serve. **Note:** Always pull the drawer out to the stop position before turning or removing food.
7. When broiling is finished, turn the Temperature Control knob to OFF.



CAUTION Should an oven fire occur, leave the oven door closed and turn the oven off. If the fire continues, throw baking soda on the fire or use a fire extinguisher. **DO NOT** put water or flour on the fire. Flour may be explosive.

Adjusting Oven Temperature

The temperature in the oven has been set at the factory. When first using the oven, be sure to follow recipe times and temperatures. If you think the oven is too hot or too cool, the temperature in the oven can be adjusted. Before adjusting, test a recipe by using a higher or lower temperature than the recommended temperature. The baking results should help you to decide how much of an adjustment is needed.



To Adjust Oven Temperature:

1. Check to be sure the Temperature control knob is in the OFF position.
2. Pull Temperature control knob straight off the shaft.
3. Loosen, but do not remove, the two screws at the back of the knob. **Note:** If knob does not have 2 screws, it is not adjustable. There is a series of small indicator grooves. One of these grooves is positioned next to a tiny pointer. Note the position of the pointer.
4. To increase the temperature, move the pointer in a clockwise direction. To decrease the temperature, move the pointer in a counterclockwise direction. The temperature can be adjusted in increments of 10°F.
5. When the desired adjustment is reached, tighten both screws.
6. To replace the knob, line up the flat sides of both the knob and the shaft. Push the knob into place. **DO NOT** force the Temperature Control knob onto the shaft or you may damage the back of the knob.

Note: Once an adjustment is made, the OFF position will vary from the reference mark on the backguard depending on the amount of adjustment.