

SERVICE DATA SHEET

This information is intended for use by persons having electrical and mechanical training and a level of knowledge acceptable in subjects generally considered acceptable in the appliance repair trade. Electrolux Home Products North America cannot be responsible, nor assume any liability, for injury or damage of any kind arising from the use of this Service Data Sheet.

P/N: 154414401


Models:
MDB122, MDB124

011112


Color Code

BK..... Black
 BU..... Blue
 BU-O..... Blue/Orange
 O..... Orange
 PK..... Pink
 R..... Red
 R-Y..... Red/Yellow
 VIO..... Violet
 W..... White

Timer Block



Cycle Chart



Wiring Diagram

