


- NOTES:
- CIRCUIT SHOWN WITH ALL CONTROLS SET TO OFF. OVEN DOOR CLOSED AND UNLOCKED.
 - COMPONENTS WITH * DO NOT APPEAR ON ALL MODELS.

316002691

LOCK MOTOR SWITCHES			
OVEN DOOR	A	B	C
UNLOCKED	OPEN	CLOSED	CLOSED
LOCKED	CLOSED	OPEN	OPEN



6	12	150	3321
5	16	150	3321
4	20	150	3321
3	18	150	3321
2	16	105	1015
1	20	105	1015

W RE AWG TEMP°C UL STYLE

316002691

WARNING

DISCONNECT POWER BEFORE SERVING UNIT.

TRACER W RE: W RE COLOR NOTED FIRST, STRIPE NEXT. EXAMPLE: GREEN W RE WITH YELLOW STRIPE.

OVEN LAMP

COLOR CODE			
BK	BLACK	P	PI NK
BL	BLUE	PR	PURPLE
BR	BROWN	R	RED
C	COPPER	T	TAN
G	GREEN	V	VI OLET
GY	GRAY	W	WHI TE
O	ORANGE	Y	YELLOW