


WIRING DIAGRAM



- NOTES:
- CIRCUIT SHOWN WITH ALL CONTROLS SET TO OFF.
OVEN DOOR CLOSED AND UNLOCKED.
 - COMPONENTS WITH * DO NOT APPEAR ON ALL MODELS.

316002651

CAM POSITION	LOCK MOTOR SWITCH CONTACTS			
	A COM-NC	A COM-NO	B COM-NC	B COM-NO
UNLOCKED	N/A		N/A	X
LOCKING	N/A		N/A	
LOCKED	N/A	X	N/A	
UNLOCKING	N/A		N/A	