



NOTE :

OVEN CONDITION:
ALL CONTROL SET TO "OFF"
OVEN DOOR CLOSED.

IMPORTANT:

COPPER WIRE MUST BE USED FOR
CONNECTIONS TO CONDUIT WIRE.

WARNING
DISCONNECT POWER
BEFORE SERVICING UNIT

TRACER WIRE :
WIRE COLOR NOTED FIRST, STRIPE NEXT.
EXAMPLE:
RED WIRE WITH WHITE STRIPE,
R/W - 10
COLOR WIRE NO.

COLOR CODE

BK	BLACK	P	PINK
BL	BLUE	PR	PURPLE
BR	BROWN	R	RED
C	COPPER	T	TAN
G	GREEN	V	VIOLET
GY	GRAY	W	WHITE
O	ORANGE	Y	YELLOW

LEGEND

X - CLOSED
O - OPEN
CY-CYCLING

WIRE	GAGE	TEMP °C	UL STYLE	CSA STYLE	CONTACTS	4 POSITION SELECTOR SWITCH			
						INDICATED DIAL POSITION			
						OFF	PRE-HEAT	BAKE	BROIL
					L1-1	C	X	CY	X
					L1-2	C	X	O	CY
					L2-3	C	X	X	O
					L2-4	C	X	X	X